



Spreader Setting Guide

Spreader Settings are approximate and will vary based on ground speed, spacing, pattern, adjustment and wear of equipment. You should always calibrate your spreader prior to applying product!

SGN 90-110

Spreader Settings

Green's Grade

	1lb. / 1000 sq. ft.	2lb. / 1000 sq. ft.	3lb. / 1000 sq. ft.	4lb. / 1000 sq. ft.	5lb. / 1000 sq. ft.	6lb. / 1000 sq. ft.	7lb. / 1000 sq. ft.
ProScape-Prizelawn Bigfoot. bf1/ss	E	F	G	H	J	L	N
PennMulch-Prizelawn HVO	E	F	G	H	J	L	N
Cyclone	-	2	2 ½	3	4	4 ½	5
Earthway Rotary	8	10	11	12	14	15	16
Gandy	18	20	21	22	24	26	28
Jet-Spred II	1 ½	2	3	3 ½	4	4 ½	5
Jet-Spred III	2	2 ½	3	4	4 ½	5	5 ½
Lely HR, 1250,1500,2010	-	2 II	2 ½ II	3 II	4 II	5 II	6 II
Lely W	-	2 II	2 ½ II	3 II	4 II	5 II	6 II
Lesco (letters)	C1	D	E	G	H	I	J
Lesco(numbers)	9	14	15	16	17	18	21
Scotts RX7	B	C	F	E	E	G	I
Scotts Accupro 2000 SR-2000	D	E	F	G	H	K	M
Scotts R8A/SR1	E	G	H	J	K	L	M
Scotts AP	E	G	H	J	J	L	M
Scotts SR2000	E	G	H	J	J	L	M
Spyker	-	-	1 ½	2	3 ½	4 ½	4 ¾
Vicon	14	15	16	18	22	24	26

SGN 140-155

Spreader Settings

Mid-size Grade

	1lb. / 1000 sq. ft.	2lb. / 1000 sq. ft.	3lb. / 1000 sq. ft.	4lb. / 1000 sq. ft.	5lb. / 1000 sq. ft.	6lb. / 1000 sq. ft.	7lb. / 1000 sq. ft.
ProScape-Prizelawn Bigfoot. bf1/ss	D	E	J	K	L	N	R
PennMulch-Prizelawn HVO	D	E	J	K	L	N	R
Cyclone	2	3	4	4 ¼	4 ½	5	6
Earthway Rotary	11	12	14	15	15	16	22
Gandy	21	22	24	25	26	28	34
Jet-Spred II	3	3 1/5	4	4 ¼	4 ½	5	6
Jet-Spred III	3	4	4 ½	5	5	5 ½	6 ½
Lely HR, 1250,1500,2010	2 II	3 II	4 II	5 II	5 II	6 II	7 ½ II
Lely W	2 II	3 II	4 II	5 II	5 II	6 II	7 ½ II
Lesco (letters)	C1	D	H	I	I	J	M
Lesco(numbers)	8	10	15	16	17	21	26
Scotts RX7	C1	D	E	F	G	I	M
Scotts Accupro 2000 SR-2000	E	F	H	I	K	M	R
Scotts R8A/SR1	H	I	K	L	L	M	P
Scotts AP	H	I	J	K	L	M	P
Scotts SR2000	H	I	J	K	L	M	P
Spyker	2	3	3 ½	4 ¼	4 ½	4 ¾	6
Vicon	18	20	22	23	24	26	32



Spreader Setting Guide

-continued-

SGN 200-220

Spreader Settings

Standard Grade

	1lb. / 1000 sq. ft.	2lb. / 1000 sq. ft.	3lb. / 1000 sq. ft.	4lb. / 1000 sq. ft.	5lb. / 1000 sq. ft.	6lb. / 1000 sq. ft.	7lb. / 1000 sq. ft.
ProScape-Prizelawn Bigfoot. bf1/ss	E	J	L	N	O	P	R
PennMulch-Prizelawn HVO	E	J	L	N	O	P	R
Cyclone	3 ½	4	4 ½	5	5 ½	5 ¾	6
Earthway Rotary	12	14	15	16	18	20	22
Gandy	22	22	28	28	30	32	34
Jet-Spred II	3 ½	4	4 ¼	5	5 ½	5 ¾	6
Jet-Spred III	4	4 ½	5	5 ½	6	6 ¼	6 ½
Lely HR, 1250,1500,2010	3II	4II	5II	6 II	6 ½ II	7II	7 ½ II
Lely W	3II	4II	5II	6II	6 ½ II	7II	7 ½ II
Lesco (letters)	D	G	I	J	K	L	M
Lesco(numbers)	10	15	17	21	22	24	26
Prizelawn CBR III	E	J	L	N	O	P	R
Prizelawn CBR II	2 ½	4	4 ½	5 ½	6	6 ½	8
Prizelawn LF-1	2	2 ½	3 ½	4	4 ½	5	6
Prizelawn MPR 1	2	2 ½	3 ½	4	4 ½	5	6
Scotts RX7	D	E	G	I	J	L	M
Scotts Accupro 2000 SR-2000	F	H	K	M	N	O	R
Scotts R8A/SR1	I	K	L	M	N	O	P
Scotts AP	I	K	L	M	N	O	P
Scotts SR2000	I	K	L	M	N	O	P
Spyker	36	4	4 ½	4 ¾	5 ¼	5 ½	6
Vicon	20	22	24	26	30	31	32